

# ENTRANCE HANDLESET Drilling Template

FOR:  
EH710, EH711, EH805

## CAUTION

Although a door can be prepared by an untrained person, we recommend that measurements and drilling be done by a skilled carpenter or locksmith.

- 1 Decide on height of door (recommended centreline is 914mm from floor).
- 2 Decide on backset (ie, distance from door edge to centre of handle).
- 3 Fold template using required backset.
- 4 Position on required height of door.
- 5 Mark the correct hole positions for the style of handleset you have purchased. Note: the two 25mm hole positions must be central to the door face.
- 6 Double check measurements against handleset before drilling into door face.
- 7 Drill 1x 54mm hole for deadbolt (EH710, EH711, EH805)
- 8 Drill 1x 54mm hole (EH710, EH711) or 1x 51mm hole (EH805) and 1x 9mm hole as per handleset purchased.
- 9 Drill 2x 25mm holes in centre of door face to the depth of latch and deadbolt.

G.D. Rutter Limited  
127 Diana Drive,  
Glenfield, Auckland  
PO Box 100-183 NSMC,  
Auckland 0745  
Phone: 09 444 5359  
Facsimile: 09 444 3972

