

DOOR PULL

Drilling Template

FOR:
DP4, DP5

- 1 Decide on height of door.
- 2 Decide on backset (i.e. distance from door edge to centre of handle).
- 3 Fold template using required backset.
- 4 Position on required height.
- 5 Mark the correct hole positions for the model you have purchased, DP4 580 mm B/C or DP5 450 mm B/C.
- 6 Mark hole positions (2 holes only).
- 7 Pilot drill 3mm holes through door.
- 8 Finish drill 8mm holes from either side of door to help prevent any splintering.

Note: For tempered glass doors (we suggest drilling to be arranged by a glass specialist), 2x 9mm holes required.

Please fit plastic bushes and feet between handle and glass before clamping on door.

NOTE: USE LONGER SCREWS FOR WOODEN DOORS.

